BILL EMLENDirector (707) 784-6765

TERRY SCHMIDTBAUER

Assistant Director (707) 784-6765

JAGJINDER SAHOTA

Environmental Health Manager (707) 784-6765

DEPARTMENT OF RESOURCE MANAGEMENT



675 Texas Street, Suite 5500 Fairfield, CA 94533-6342 (707) 784-6765 Fax (707) 784-4805

www.solanocounty.com

Environmental Health Division

UST Permit Work Guidance

The following guidance shall be used by staff to decide which UST work to permit and which fee category to use:

1. Plan Check / Construction Inspection

a) Install Underground Storage Tank

2. Modification / Repair (tank)

- a) Add or Replace STP, Vapor, or Vent Sumps
- b) Add, Repair, Replace, or Modify Riser outside sump.
- c) Repair Tank / Modify Tank
- d) Repair, Install or Inspect Tank Lining
- e) Install or Repair Tank Cathodic Protection

3. Modification / Repair (piping only)

- a) Add or Replace Spill Bucket (riser top work only, inside or outside sump)
- Add or Replace Vapor Recovery (VR) spill bucket inside or outside monitored sump.
- c) Repair or replace Penetrations external to sump/UDC.
- d) Add or Replace Dispenser Pan (UDC) or Island
- e) Add, replace or modify dispenser components below sheer valve.
- f) Replace dispenser if footprint does not match current UDC configuration.
- g) Add, Replace, Repair or Modify Regulated Pipe.
- h) Add, Replace, Repair or Modify unregulated pipe (pre-7/2003 Vent, VR in concert with disturbing product lines and/or the breaking of concrete/asphalt).
- i) Add, Replace, Modify or Repair riser in sump
- j) Install or Repair Piping Cathodic Protection

4. Non-Permit Work (Documentation Required)

- a) Repair or replace Penetrations internal to sump/UDC.
- b) Add or Replace Overfill Protection
- c) Add or Replace Monitoring Console or Electronic Relay.
- d) Add or Replace Sensor or In-Line Leak Detector
- e) Add or Replace Tank Level Monitor or External Overfill Protection Enunciator
- f) Reprogram Monitoring Console / Cold Start / Console Upgrade.